clip&talk[™]



USER MANUAL

www.clipandtalk.com



warranty

register now to get your clip&talk warranty activated

to activate your clip&talk warranty you will need to send us an email at

warranty@clipandtalk.com within 30 days from date of purchase with the following information: 1. name & surname 2. where did you purchase your clip&talk from? 3. date of purchase 4. telephone number

product warranty terms

your clip&talk carries a one-year limited warranty against defects in materials and workmanship

what isn't covered

the warranty will not cover product failure because you broke it (any defect or malfunction that is caused as a result of misuse, failure to follow operating instructions, abuse, or use with improper or faulty equipment), it doesn't cover incidental damages, also, the warranty isn't any good after you open any product that isn't intended to be opened - please don't try and fix anything yourself. this warranty does not provide service or support for any of the third party products used with the clip&talk, including, but not limited to mobile phones and tablets.

documentation and making a claim

to help ensure warranty claims are for the genuine clip&talk, our warranty support department may require a receipt to complete your claim. if a receipt is required, you will be emailed requesting a copy be attached and sent to us via email to make a claim email us at

warranty@clipandtalk.com with the following details: : 1. name & surname 2. where did you purchase your clip&talk from? 3, date of purchase 4, telephone number 5, what problems or defect you are experiencing with your clip&talk, we will, at our discretion, repair or replace any product that proves to be defective in material or workmanship, if your product is no longer being manufactured or is out of stock, we may replace your product with a similar or better product at our option.



contents

- 1 congratulations & thank you
- 2 what your clip&talk does
- 3 4 key features of your clip&talk
- 4 about your clip&talk
- 5 getting started
- 6 charging your clip&talk
- 7 turning your clip&talk on & off
- 8 pairing your clip&talk to your mobile device
- 9 pairing your clip&talk to a second mobile device
- 10 how to practically operate your clip&talk
- 11 using your clip&talk with 2 mobile devices
- 12 how to answer, terminate, reject and redial a call
- 13 how to adjust the volume of your clip&talk
- 14 using your clip&talk to play music from your mobile device
- 15 mobile phone theft/loss feature of clip&talk
- 16 playing audio from popular apps/gps/call services
- 17 how to wear your clip&talk
- 18 voice prompts of your clip&talk
- 19 safety, tips and how to take care of your clip&talk
- 20 battery level indicator
- 21 using siri (iphone ios) & other speech recognition applications with your clip&talk
- 22 how to reset your clip&talk
- 23 usb memory function
- 24 technical specifications
- 25 function table





1. congratulations & thank you

congratulations on purchasing your clip&talk! clip&talk is a world first patented product that puts your safety, health & productivity first! thank you for your purchase & be sure to use your clip&talk as shown in this user manual so that you can enjoy the maximum safety and convenience benefits!

2. what your clip&talk does

- make & receive calls from your mobile device wirelessly & hands free
- listen to music & audio from your mobile device wirelessly & hands free
- single earphone, clip & bluetooth unit that allows you to clip it on your clothing, bags and other items for easy and convenient carrying and immediate accessibility when receiving a call
- 2-3 second automatic phone connect and call answer which allows you to keep your clip&talk off when not in use for infinite standby time & to conserve clip&talk & mobile phone battery
- plays audio from popular apps and mobile services such as skype, voutube, wechat, viber. facebook chat .facetime and qq.
- plays the audio of your gps application on your mobile phone so that you can hear all instructions for directions clearly and directly in your ear
- supports voice command/speech recognition features of your mobile device such as Siri (apple ios) and other speech recognitions applications
- multi point-can be used for 2 mobile devices simultaneously
- alert if phone is distanced from user (theft / phone forgotten)
- · voice prompts for easy use
- rotating clip which doubles up as a memory stick and charging device
- clip&talk battery level indicator (iphone only)
- · works with mobile phones, tablets, computers & other bluetooth enabled devices
- volume control
- play / pause / next previous song control
- · independent answer button when powered on



3. 4 Key features of your clip&talk

earpiece & clip 1 single unit



clips on clothes, bags etc for easy use and carrying



2-3 second automatic phone connect & call answer when switched ON-saves battery life



easy to use-when receiving call unclip turn ON & talk turn OFF & clip on when finished






clip&talk"

be safe • be healthy • be productive

4. about your clip&talk



- 8 earbuds
- · usb cable
- · 2 earhook



born on The Avenue of The Americas, NYC



5. getting started

please attend to the following items before using your clip&talk:

- charge your clip&talk (see 6 below)
- activate the bluetooth function on your mobile device (refer to the manual of your mobile device)
- pair your clip&talk with your mobile phone/mobile device (see 8 below)

6. charging your clip&talk

(please refer to the diagram in 4 above)

- . make sure that the ON/OFF switch of your clip&talk is in the OFF position
- swivel the clip to the right as shown in 4, above and place the USB into the USB port of your computer or usb wall charger
- . when the clip&talk starts to charge the indicator light will turn on with a red color
- allow the clip&talk to fully charge (+/- 2 hours). once it has fully charged the red indicator light will turn off

the lifetime of the battery will be significantly reduced if your clip&talk is left uncharged for a long period so please ensure that you recharge your clip&talk at least once a month.

"IMPORTANT": the connection terminals are on one side of the USB. If you place the USB into the USB port of your computer or usb wall charger and it does not start charging (indicator light turns RED) PLEASE INSERT THE USB THE OTHER WAY AROUND SO THAT THE CONNECTION TERMINALS OF THE USB ARE MAKING CONTACT WITH THE CONNECTION TERMINALS OF YOUR USB PORT OR USB WALL CHARGERS.

7. turning your clip&talk ON & OFF

(please refer to the diagram in 4 above)

- to turn your clip&talk ON simply push the ON/OFF switch upwards to the ON position
- to turn your clip&talk OFF simply push the ON/OFF switch downwards to the OFF position





8. pairing your clip&talk to your mobile device

your clip&talk connects to mobile phones and other bluetooth enabled devices such as tablets. mp3 players, laptops & computers using a procedure called "pairing" which is simple and can be done easily and quickly by following the below steps:

- make sure the bluetooth feature of your device is turned on (refer to your mobile device user manual on how to do this) and that your mobile device and clip&talk are close to each other (10cm - 20cm)
- turn your clip&talk ON, the indicator light will start flashing red & white alternately and the voice prompt will say "pairing". your clip&talk is now ready to pair
- open the bluetooth menu of your mobile device and "search for new devices" and in a few seconds you will see "clip&talk alu"
- choose "clip&talk alu" and wait until your mobile device and your clip&talk connect, if your mobile device asks for a pass code please enter 0000, as soon as connection is achieved the voice prompt of your clip&talk will say "your headset is connected"

Note.

- make sure you complete the above steps within 3 minutes of switching your clip&talk ON as it remains in pairing mode for maximum 3 minutes
- repeat the above steps should pairing not be successful on your first try, sometimes it may take 2 – 3 attempts to get a successful pairing depending on the make and model of mobile phone/device you have





9. pairing your clip&talk to a second mobile device

your clip&talk can be used with 2 mobile devices simultaneously, to pair with a **second mobile device** please follow the below steps:

- after successfully pairing with your first mobile device as specified in 8 above turn your first mobile device OFF or deactivate the bluetooth feature of this device and then turn your clip&talk OFF.
- make sure the bluetooth feature of your second mobile device is turned on (refer to your mobile device user manual on how to do this) and that your second mobile device and clip&talk are close to each other (10cm – 20cm)
- turn your clip&talk ON. the indicator light will start flashing red & white alternately and the voice prompt will say "pairing". your clip&talk is now ready to pair.
- open the bluetooth menu of your second mobile device and "search for new devices" and in a few seconds you will see "clip&talk alu"
- choose "clip&talk alu" and wait until your second mobile device and your clip&talk connect.
 If your second mobile device asks for a pass code please enter 0000, as soon as connection is achieved the voice promot of your clip&talk will say "your headset is connected".

once paired with the second mobile device turn your clip&talk OFF, then make sure that both your mobile devices are furned ON with the bluetooth function activated, turn your clip&talk ON and it will automatically connect to both mobile devices & you will hear the voice prompt "your headset is connected" for each time it connects with each mobile device, if one of your devices does not automatically connect with your clip&talk, switch your clip&talk OFF and then switch it back on again, if the device still does not automatically connect navigate to the bluetooth settings of this device, make sure that the bluetooth feature is activated and connect manually to your clip&talk by pressing "clip&talk alu" on the list of paired devices, if you continue to have pairing problems we suggest that you reset your clip&talk (see 22 below), delete clip&talk as a device from the paired list on both your mobile devices and then follow the steps in 8 & 9 again.



10. how to practically operate your clip&talk

your clip&talk has great unique features — the first unique feature is that the whole unit is a clip which clips on your clothes bags etc for easy carrying and immediate accessibility! the second unique feature is that when you turn it ON it automatically connects to your mobile device and automatically answers an incoming call all in approximately 2-3 seconds.

· the unique recommended practical way to use your clip&talk

make sure you are clip&talk is OFF, clip it on your shirt, bag, clothing etc.

when receiving a call simply unclip, turn **0N**, place in your ear & start talking! (your clip&talk automatically connects to your mobile device & answers your call in 2 – 3 seconds!), when you finish your call turn your clip&talk **OFF** & clip it back on! SD EASY, SD CONVENIENT, SD SIMPLE, SD SAFE! & the great feature is that because your clip&talk is **OFF** when it is clipped on, you have infinite standby time & you save the battery life of your clip&talk & your mobile device!

If you want to make a call simply unclip, turn ON, place in your ear, dial or select your number and make your call! (your clipătalk automatically connects to your mobile device in 2 - 3 seconds), when you finish your call turn your clipătalk OFF & clip it back on! SO EASY, SO CONVENIENT, SO SIMPLE. SO SAFE!



easy to use-when receiving call unclip turn ON & talk, turn OFF & clip on when finished





10. how to practically operate your clip&talk continued...

when you are in your car we recommend that you use your clip&talk as follows:

before you start driving unclip your clip&talk, turn it ON and place it in your ear, it will automatically connect to your mobile phone and you will hear "your headset is connected", keep the clip&talk in your ear for the entire duration of your driving.

place your mobile phone on a reliable car mount so that you can clearly see the screen without having to move close to it or touch it.

when a call comes in you will hear the ringing sound through your clip&talk in your ear and you will answer by pressing the multifunction button (see 4 above). When your call is complete you can terminate it by pressing the multifunction button again.

- avoid any contact with your mobile phone whilst driving
- avoid making any calls if it is absolutely necessary to make a call stop your car slowly in a safe area far away from any danger or traffic, dial your number and once your call is active through your clip&talk you can start driving again, be extra careful when entering traffic again, you can also make a call by using Siri (iphone ios) or other speech recognition features of your mobile device (see 21 helow)
- answer only calls that are absolutely necessary if a call comes in and you absolutely have to take it, answer it as specified above

Note: some countries prohibit using a mobile phone in the car even with a bluetooth headset so make sure you are aware of your local country laws.

your safety and the safety of others around you comes FIRST & is a priority!

when you have finished driving, take your clip&talk out of your ear, turn it OFF, clip it on your clothes, bag etc and exit your car.





11. using your clip&talk with 2 mobile devices

your clip&talk can connect to 2 mobile devices simultaneously, this allows you to use the features of your clip&talk for both devices, please follow the instructions in 8 and 9 above on how to pair and connect your clip&talk to 2 mobile devices,

12. how to answer, terminate, reject & redial a call

- answering a call you can answer a call in 2 ways with your clip&talk. the first way is by simply
 turning it ON. it will automatically connect with your mobile phone and answer your call in 2-3
 seconds. the second way is by simply pressing the multifunction button (this way requires that
 your clip&talk is already switched ON before your call comes in) see 10 above
- terminating a call you can terminate a call in 2 ways with your clip&talk. the first way is by simply pressing the multifunction button. the second way is by pressing the end/termination button on your mobile phone
- rejecting a call if your clip&talk is switched OFF when your call comes in you can reject it by
 pressing the reject button on your mobile phone. if your clip&talk is switched ON before your
 call comes in you can reject it by double pressing the multifunction button
- redialing a call —you can redial a call in 2 ways with your clip&lalk. the first way is by double
 pressing the multifunction button (this way requires that your clip&talk is already switched ON
 and connected to your mobile phone), the second way is by redialing directly from your mobile
 phone

13. how to adjust the volume of your clip&talk

you can adjust the volume of your clip&talk during a call or whilst listening to audio/music by simply long pressing the volume "+" or "-". once the volume reaches the maximum or minimum level you will hear a beep, we suggest that you also adjust the volume control directly from your mobile of the pression the volume buttons usually found on the side of your mobile device

14. using your clip&talk to play music from your device

- play music you can hear your music played from your mobile device on your clip&talk, make sure your clip&talk is turned **0N** and connected to your mobile device, select the song/s you want to hear and press play on your mobile device, you can pause the song by short pressing the multifunction button and short pressing it again to resume playback.
 for iPhone you can also start playing your music simply by turning your clip&talk **0N** and pressing the multifunction button once
- changing tracks you can change tracks to the next song by short pressing the volume "+"
 button and change tracks to the previous song by short pressing the volume "-" button
- . adjusting the volume see 13 above on how to adjust the volume

15. mobile phone theft/loss feature of clip&talk

your clipAtalk can assist in preventing loss/theft of your mobile phone, when your clipAtalk is in your ear and connected to your mobile phone it will sound an alarm saying "beyond the range of connections" when your mobile phone is distanced more than 8 – 10 meters from your clipAtalk. this way you will know that you have either forgotten your mobile phone or it has been taken from you

16. playing audio from popular apps/gps/call services

your clip&talk allows you to hear the audio from popular apps & call services such as Skype, Viber, Facebook Chat, Wechat, QQ.in addition to this it allows you to hear the audio of your gps application on your mobile phone like Google Maps and Apple Maps. Simply turn it **ON**, make sure it is connected to your mobile phone and run your apo/qos/call service



17. how to wear your clip&talk

- on your body when not in use wear your clip&talk by simply clipping it on your shirt, clothes, bag etc SO EASY AND SO SIMPLE
- . on ear your clip&talk comes with an earbud and earhook accessory, we suggest that you place it in your ear only with the earbud and see if it positions firmly, you can also adjust the little "ear" of the earbud to the left or to the right which will give you a firmer hold and placement (be careful not to damage the earpiece when moving the little ear left or right). if the earbud is not enough for a firm placement in your ear then clip on the earhook and use it as well

18. voice prompts of your clip&talk

your clip&talk has voice prompt features which make it really easy to use, these voice prompts are heard under the following circumstances:

- . "power on" this is heard when you switch your clip&talk ON
- . "pairing" this is heard when your clip&talk is ready to pair
- . "your headset is connected" this is heard when your clip&talk has connected with your mobile device
- . "power off" this is heard when your clip&talk is switched OFF
- . "your headset is disconnected" this is heard when your clip&talk is disconnected from your mobile device
- . "beyond the range of connections" this is heard when your mobile device is distanced more than 8 - 10 metres from your clip&talk
- "battery full" this is heard when your battery is full
- . "battery level high" this is heard when the battery level is high
- . "battery level medium" this is heard when the battery level is medium
- . "battery level low" this is heard when the battery level is low
- · "recharge headset" this is heard so you can recharge
- . "incoming call" this is heard on android mobile phones when there is an incoming call



19. safety, tips and how to take care of your clip&talk

- high volume avoid high volume as it can lead to hearing loss, adjust the volume of your clip&talk to a comfortable level and which is not louder than needed to hear your call
- . cleaning clean your clip&talk with a soft dry cloth
- water keep your clip&talk away from water any contact with water will damage your clip&talk
- storage do not store or use your clip&talk in temperatures below 15°C or higher than 55°C otherwise battery life will be reduced
- . usb charging clip swivel the clip without force to the right in order to charge
- removal of battery do not attempt to remove the battery from your clip&talk, it is a built-in rechargeable battery

20. battery level indicator

the battery level of your clip&talk can be seen on the top right corner of your iOS device. note that this feature is not available on android or other mobile devices

21. using siri (iphone ios) and other speech recognition applications with your clip&talk

your clip&talk supports Siri (iphone ios) and other speech recognition applications found on your mobile device.

you can activate Siri or other speech recognition/voice command applications and give voice commands directly from your clip&talk by simply double pressing the volume "+" button

22. how to reset your clip&talk

vou can reset your clip&talk by pressing both volume + & - buttons continuously for 5 - 7 seconds, in order for this to work your clip&talk must be on and NOT connected to your device. after resetting your clip&talk please follow the instructions and steps specified in this manual so that you can pair it with your mobile devices and start using it again, we suggest that you reset your clip&talk in the following cases:

- you have new mobile devices and want to erase all prior pairing of your clip&talk with your old mobile devices so that you can pair successfully with your new mobile devices
- vour clip&talk is not functioning correctly or as specified in this manual
- your second mobile device is not successfully pairing or connecting with your clip&talk

23. usb memory function

Your clip&talk also functions as a usb memory stick, simply insert a micro sd card in the slot shown in 4. above, swivel the clip to the right and place it into the usb of your computer. note that the maximum capacity micro sd card that you can use is 32GB

24. technical specifications

- Bluetooth V4.1
- · supports HSP, HFP, A2DP, AVRCP
- transmitting power: class 2
- · working distance: <= 10m
- frequency range: 2,4026GHz 2,480GHz charging time <= 2 hours
- talk time <= 5 hours
- music time <= 4 hours standby time when switched ON : <= 70 hours
- standby time when switched OFF: <= 1 year
- · weight 15g



25, function table

multifunction button	Switch ON/OFF	VOL+	VOL -	Voice prompt	Indicator light
	quitals to ON				white and red light
				power on	flash alternately
	position				once
	nuitals to ON			pairing	white and red light
					flash alternately
	p				quickly
	switch to OFF			power off	red light flashes
	position				once
					white light flashes
short press				"doo beep"	once every 3
					seconds
					white light flashes
double short press				"doo"	once every 3
·					seconds
short press				"doo"	white light flashes
					once
					white light flashes
		double press		"doo"	once every 3
					seconds
			double press	"doo"	red light flashes
double press				"doo"	white light flashes
short press					white light flashes
					twice every 3
					seconds
					white light flashes
short press					once every 3
					seconds
			short press		
		short press			
		long press		"beep" when max	
				volume reached	
				"doo" when	
			long press	minimum volume	
				reached	
	short press double short press short press double press short press	multifunction button Seetic NUVOFF Selfich to ON position Selfich to ON position Selfich to ON position Selfich to OFF Selfich to	switch to ON position switch to ON position switch to ON position switch to OP position switch to OPF position switch to OPF position short press short press double press short press sho	multifunction button Seelich (MVDEF VOIL + VOIL + VOIL + Seelich to ON position	midrifunction button Seatch ON/OFF VOL + VOL - Volce prompt



support please email us at:

support@clipandtalk.com

© 2015 clip&talk IIc. all rights reserved. all trademarks specified herein are the property of their respective owners, the bluetooth® word, mark and logos are owned by the bluetooth sig, inc. and any use of such marks is under license, design and specifications subject to change without notice.

clip&talk[™]

be safe • be healthy • be productive

NOTES	



clip&talk

be safe • be healthy • be productive

eered & designed by CT in New York City assembled in PRC | Patent Protected Product MODEL: clip&talk aluminum

